

Sonneville AG  
Industriezone 2 | CH-3225 Müntschemier

Tel. +41 32 312 98 50 | Fax +41 32 312 98 88  
mail@sonneville.com | www.sonneville.com

**LOW VIBRATION TRACK SYSTEM –  
LVT**

# Track Adjustment and Component Substitution

Document no: DCM009.GN  
Revision date: February 2017

**sonneville**

© 2022 This document has copyright, which is owned by Sonneville AG and may not be reproduced, in whole, in part or in any form whatsoever without prior written authority from Sonneville. This document has been submitted on the understanding that it will not be used in any way against the interest of Sonneville.

If an LVT component requires replacement or if vertical adjustment becomes necessary, the following procedure applies:

1. The rail fastenings are released over a length of approximately 10 m (30 ft) on both sides of the work area.
2. The rail is lifted with two or more (depending on the length of the work area) standard rail jacks as shown or equivalent equipment, the affected concrete blocks remaining fastened to the rail.



3. Once the base of the concrete blocks clears the track concrete by a maximum height of 200 mm (8 in), the rail is secured in place.



- If a block pad or rubber boot needs to be replaced, that component is removed and substituted by a new one.
  - If a concrete block needs to be replaced, the corresponding cavity in the track concrete is covered with plywood, the rail fastenings are dismantled, the block is lowered onto the plywood and slid away, a new block is slid under the rail and the rail fastenings are re-assembled and tightened.
  - If vertical adjustment is required, shims of appropriate thickness are inserted under the concrete blocks (over the block pads) up to a maximum adjustment height of 25 mm (1 in).
4. The rubber boots are pulled up onto the concrete blocks and secured in place.
  5. The rail is lowered back into its original position.

The manufacturing tolerances specified for the rubber boot and block pad dimensions and the resiliency of their materials provide for direct interchangeability.

For concrete block replacement purposes, tight dimensional tolerances are specified to ensure that new blocks will fit in the track concrete cavities left by damaged ones.



Sonneville can also provide a video demonstrating the component exchange and the adjustability of the top of rail level with HDPE shims. Please send an e-mail to [mail@sonneville.com](mailto:mail@sonneville.com) and we will give you a download link for the video.